



HOOF ARMOR DISPENSER ASSEMBLY



Step 1. Two pieces of dispenser, body and plunger. Place thumb under silver tab. Also the ridges of the plunger should be facing down.



Step 2. While lifting up on the silver tab begin sliding the plunger into the dispenser gun.



Step 3: Continue sliding the plunger into the dispenser until fully inserted.



Step 4. Empty assembled dispenser.



Step 5. Black clip closed.



Step 6. Flip open black clip.



Step 7. Slip cartridge into dispenser matching large and small openings in the cartridge with the large and small openings in the dispenser.



Step 8: Snap black clip closed.



Step 9: Remove small cap from end of product cartridge by turning the cap a quarter turn counter clockwise.



Step 10: Add mix nozzle to end of the product cartridge by turning the mix nozzle a quarter turn clockwise. It should lock into place.



One mix nozzle should be used per foot. There is very little Hoof Armor which remains in the mix nozzle as most of the mix nozzle is filled with plastic mixing channels. Hoof Armor will set up in a mix nozzle between feet. When you are done applying Hoof Armor to the last hoof you can leave the last mix nozzle on the product cartridge until the next time you apply Hoof Armor.